

# CHO-BOND® 1085 and 1086 Silicone Adhesive Primers



## Customer Value Proposition:

Parker Chomerics CHO-BOND primers 1085 and 1086 are air-drying liquid coatings used to improve the adhesion of Parker Chomerics CHO-BOND conductive silicone compounds to metal and other non-silicone substrates. The primers are moisture reactive and clear in color. CHO-BOND 1085 primer is formulated to achieve maximum adhesion on non-silicone substrates for CHO-BOND 1029 adhesive. CHO-BOND 1086 primer is formulated for use with CHO-BOND 1016, 1030, 1035, 1038, 1075 electrically conductive adhesives/sealants and CHO-THERM® 1641 thermal compound.


Note that typically, the proper primer comes bundled as a “kit” with the CHO-BOND or CHO-THERM compound ordered. However, if extra primer is deemed necessary, then part numbers for just the primer are provided in Table 2. See the Conductive Compounds Selector Guide for a more detailed listing of which CHO-BOND adhesive / sealant part numbers come packaged as a kit with the primer and which do not.

## Contact Information:

Parker Hannifin Corporation  
**Chomerics Division**  
77 Dragon Court  
Woburn, MA 01801

phone 781 935 4850  
fax 781 933 4318  
chomailbox@parker.com

www.chomerics.com  
www.parker.com/chomerics



## Typical Applications:

For best bonding results, use the following procedure:

1. Surfaces to be joined must be clean, dry and oil free. In a well-ventilated area, clean the substrates with isopropyl alcohol (IPA) and let the solvent flash off. (Other solvents, such as methyl-ethyl-ketone (MEK), toluene, or acetone can be used to clean difficult to remove contaminants).
2. Wet a lint-free cotton cloth with the primer and apply to the surface in horizontal and vertical strokes. Keep the surface wet at all times. A cotton swab is a common applicator for a grooved or stepped surface.  
**NOTE:** Due to the low flash point temperature of the primer, ensure that the container is re-sealed immediately after use.
3. The primed surface must cure for 30 minutes at room temperature. A relative humidity of 40% to 70% is optimal. A low humidity level may require a longer cure time.  
**NOTE:** There is no elevated temperature cure time for the primer.
4. Apply the CHO-BOND / CHO-THERM adhesive / sealant per that product's instructions.  
**NOTE:** If the primer has been applied for more than 4 hours without the application of the adhesive / sealant, repeat steps 1 through 4.

ENGINEERING YOUR SUCCESS.

## CHO-BOND Primers 1085 and 1086 - Product Information

**Table 1 Typical Properties**

<b>CHO-BOND® Primers 1085 and 1086</b>		
<b>Typical Properties</b>	<b>Primer 1085</b>	<b>Primer 1086</b>
Viscosity @ 25°C (77°F), centipoise	5	5
Color	Clear	Clear
Specific Gravity	0.82	0.80
Flash point, °C (°F)	14 (57)	6 (43)
Use Temperature, °C (°F)	-80 to 200 (-112 to 392)	-80 to 200 (-112 to 392)
Elevated Temperature Cure	None	None
Room Temperature Cure	0.5 hr	0.5 hr
Working Life	N/A	N/A
Shelf Life, unopened, from Date of Manufacture	9 months at 25°C (77°F)	9 months at 25°C (77°F)
Minimum thickness recommended	0.0001 in (0.00254 mm)	0.0001 in (0.00254 mm)
Maximum thickness recommended	0.0005 in (0.01270 mm)	0.0005 in (0.01270 mm)
Volatile Organic Content (VOC)	731 g/l	774 g/l

**Table 2 Ordering Information**

<b>Product</b>	<b>Weight (grams)</b>	<b>Packaging</b>	<b>Part Number</b>
CHO-BOND 1085	400	1 pint can	50-01-1085-0000
CHO-BOND 1086	10	3 dram glass vial	50-10-1086-0000
	95	4 fluid ounce glass bottle	50-04-1086-0000
	375	1 pint can	50-01-1086-0000

[www.chomerics.com](http://www.chomerics.com)  
[www.parker.com/chomerics](http://www.parker.com/chomerics)

CHOMERICS and CHO-BOND is a registered trademark of Parker Hannifin Corporation. © 2013

TB 1142 EN January 2014



ENGINEERING YOUR SUCCESS.